


**Connection scheme for Lumoluce LED lighting**

**Attention: Always disconnect the mains of the driver before plugging or unplugging the LEDs.**

The high voltage on the driver output (when no load is connected to the driver) will damage the LEDs.

**Use the 'Short link':**

The LEDs are always connected in series, so you will need to close the circuit with an extra plug (Short link) when only one LED module is connected.



**Max. cable length:**

Extension wires can be used to extend the cable length where needed. The recommended **max.** cable length from the Driver to the last LED module is **10 meter**.

